



Processing advice photo wallpaper with non-woven backing / smartpaper

Is substantially stronger than normal paper (wallpaper). Does not contain environmentally and health-damaging substances and is biodegradable. Can be removed dry from the wall after use (when using Perfax pink for fleece).

- The surface must be dry, clean, firm, smooth, even in color and absorbent. On light surfaces, color deviations in the surface can show through!
- The poster webs hardly expand and hardly shrink. This allows the adhesive to be applied to the wall with a roller and the dry wall covering to be applied to the glued wall.
- The recommended adhesive is Perfax pink for fleece. Application of this adhesive later means effortless removal of the wall covering. The adhesive should be applied to the wall at a width of just over 1 strip. Apply the first strip perpendicular to this and press with a rubber roller or spatula while removing any air bubbles. Apply all subsequent strips with a bump.
- Remove any glue stains immediately with a wet cloth and then pat dry.
- Avoid too high temperatures or strong drafts during the drying process, this can cause open seams!

Note the courses are alternately straight and printed upside down so that any minimal deviations are overcome.

